



SNUG ThermScrews

Part Code: THERMSCREWS

OVERVIEW

ThermScrews are specifically designed for fixing our Snug insulation construction boards down to both concrete and wood subfloors.

It is advised that 15 of the galvanized washers should be used to fix down each 600 x 1200 board.

The ThermScrews are available in packs of 50 (50 washers and 50 screws in each pack).

The screw gauge is 3.5mm with a counter sunk Philips head and the galvanized washers are 0.9mm thick.



KEY FEATURES

- Available in packs of 50
- Available from stock
- Next day delivery available